In the Hand Hole on the South West corner of South East 47th Terrace and Coronado Parkway, splice the 24ct lateral from Cape Lee Tran Blue Buffer pairs 1 & 2 Blue, Orange, to the DOT 72 ct White Buffer pairs 69 & 70 Yellow, Violet. Splice the 24 ct lateral from Cape Lee Tran Orange Buffer pairs 13 & 14 Blue, Orange, to the DOT 72ct White Buffer pairs 71 & 72 Rose, Aqua.

At the Hand Hole South West Corner of Coronado Parkway and Cape Coral Parkway splice the 72 ct DOT White Buffer, pairs 69,70,71,72, Yellow, Violet, Rose, Aqua to the DOT 96ct Black Buffer pairs 93,94,95,96 Yellow, Violet, Rose, Aqua.

At the Node cabinet on the North East Corner of Delprado Blvd and Cape Coral Parkway. Cross through jumpers have already been installed from the 96ct DOT West Black Buffer pairs 93,94,95,96 Yellow, Violet, Rose, Aqua to the DOT 96ct North Black Buffer pairs 93,94,95,96 Yellow, Violet, Rose, Aqua.

Veteran Parkway and Delprado at the Hand Hole under the overpass on the East side, splice the DOT 216 ct South Black Buffer pairs 93 & 94 Yellow Violet to the DOT 216 ct East Violet Buffer pairs 119 & 120 Rose Aqua. Splice the DOT 216 ct South Black Buffer pairs 95 & 96 Rose Aqua to the ITG 48ct North Orange Buffer pairs 23 & 24 Rose Aqua

Created by Rick Parker 5-10-17